


DAMPER INSTALLATION INSTRUCTIONS

Installation and Maintenance Instructions 1-1/2 Hours Rated, UL Classified model 75 fire dampers For use in fire barriers with ratings of less than 3 hours

DAMPER BEHIND A GRILLE

- 1. Perimeter mounting angles to be a minimum of 1-1/2 x 1 -1/2 x 16GA on dampers 36 x 50 and smaller. For dampers greater than 36 x 50, angles to be a minimum of 1-1/2 x 1-1/2 x14GA.
- 2. Grille to flange fasteners cannot penetrate fire wall (see note 4).
- 3. Secure angles to sleeve only, so as to frame the wall opening. Fasten to the sleeve only using the same means as required for fastening the damper to the sleeve.
- 4. Grille to flange attachment by means of 1/4" dia. Pop rivets, #8 sheet metal screws or #8 bolts and nuts. Fasteners to be plated steel or stainless steel, minimum two fasteners per side.


SLEEVE MOUNTING ANGLE VERTICAL TYPE "B" HORIZONTAL



TYPE "CR"

The factory supplied 22 GA. Collar to 18 GA cap connection on type "C, CR" dampers is a breakaway connection under the following conditions:

- 1. Round unit duct diameters are no larger that 52"
- 2. Oval duct sizes are no larger that 58" W x 29"H.
- 3. Duct gauges shall conform to the SMACNA or ASHRAE duct standard.
- 4. Duct diameters of 22 inches(559mm) and smaller shall have 3 No. 10 (4.8mm) diameter sheet metal screws evenly spaced around the circumference of the duct.
- 5. Duct diameters greater than 22 inches and up shall have 5 sheet metal screws evenly spaced around the circumference of the duct.
- 6. Dampers outside of these restrictions (ie) multiple damper and special size and application dampers must use a 4" wide drawband connection as shown in the SMACNA Fire, Smoke, and Radiation Damper Installation Guide.





INSTALLATION INSTRUCTIONS IN CONFORMANCE TO UNDERWRITERS LABORATORIES REQUIREMENTS

231 Commerce Dr. Montgomeryville, PA 18936 Tel: 215-412-4445 Fax: 215-412-4409 Email: lloydind@firedamper.com 138 Industrial Loop West, Orange Park, FL 32073 Tel: 904-541-1655 Fax: 904-541-1657 Email: lloydind1@bellsouth.net B1, 4/F., Luen Ming Hing Factory Building 36 Mok Cheong St., To Kwa Wan, Kowloon, H. K. Tel: 852-2760-4188 Fax: 852-2760-4177 Email: tatanlexyim@lloydasia.com





SLEEVE INSTALLATION INSTRUCTIONS

ATTACHMENT:

BLADE CHANNEI

Attaching Fire Dampers to Sleeves

Fire dampers must be attached to sleeves as shown in Fig. 1. All four sides of the damper frame must be attached to the sleeve with one row of attachments on each side of the blade channel. Attachments must be spaced a maximum of 6" on centers and a maximum of 2" from corners. A minimum of 4 attachments (2 on each side of the blade channel) per side (16 per damper) are required. One of the methods of attachment shown below must be used.

- tack or spot welds
- No.10 sheet metal screws
- 1/4" bolts and nuts
- 3/16" steel pop rivets


Securing Fire Damper and Sleeves to Wall and Floor Openings

Fire damper and sleeve assemblies must be installed in wall and floor openings using retaining angles on each side of the wall or floor as described below:

- Retaining angles must be a minimum of 16 gauge steel and have a minimum of 1-1/2" x 1-1/2" legs.
- Retaining angles must be attached to the sleeve using the procedures and methods described in section 3. The angles must be attached to all 4 sides of the sleeve with butt joints at each corner. A minimum of two attachments are required on each side, top and bottom. The angles need not be attached to each corner. A minimum of two attachments are required on each side, top and bottom. The angles need not be attached to each other at the corners.
- Retaining angles must completely cover the clearance space between the sleeve and the wall/ floor opening, plus overlap the wall/floor a minimum of 1". This coverage includes all corners (fig. 2).
- Retaining angles should not be fastened to the wall/ floor material. The angles should only sandwich the wall/floor and allow for damper/sleeve expansion during periods of intense heat.
- For grille installation, angle legs may be reversed and one leg inserted into the wall/floor opening providing the required clearance is maintained between angle leg fasteners and the wall/opening.

NOTE:

Attachment must not enter blade channel or they may cause interference with blade closure. Narrow line and ultra thin dampers do not have flange for attachments and must be welded to sleeve.






Fig. 2

Multiple section fire dampers

When multiple sections are shipped unassembled, installer shall fasten dampers together.



INSTALLATION INSTRUCTIONS IN CONFORMANCE TO UNDERWRITERS LABORATORIES REQUIREMENTS

231 Commerce Dr. Montgomeryville, PA 18936 Tel: 215-412-4445 Fax: 215-412-4409 Email: lloydind@firedamper.com

138 Industrial Loop West, Orange Park, FL 32073 Tel: 904-541-1655 Fax: 904-541-1657

Email: lloydind1@bellsouth.net

B1, 4/F., Luen Ming Hing Factory Building 36 Mok Cheong St., To Kwa Wan, Kowloon, H. K. Tel: 852-2760-4188 Fax: 852-2760-4177 Email: tatanlexyim@lloydasia.com

