



At the beginning of the cooling season, insert the proper size Drain Strip in the condensate drain pan of your AC unit, it is okay if you have to put it on edge. Do not block the drain hole itself. Remove last year's product, wrap it in newspaper and discard with the normal garbage, being sure to wash your hands after handling both new and old products. If you are in an "all year" cooling area such as south Florida it is recommended that you use a new strip every six months.

- 1> For small window units, dehumidifiers, and small mini-splits use the BK-14
- 2> For PTAC'S, larger window units, Mini-splits over 12,000 btu, and small residential A/C systems up to 2.5 ton install the BK-28
- 3> For normal residential Ac systems 3 to 5 tons install the BK-65
- 4> For commercial applications up to 10 tons use the BK-150
- 5> For large commercial Unit 12 to 25 tons use the BK-300
- 6> For larger units use the BK-300D which is 24 inches long

For the first 2 weeks or so the strip will release a strong dose of micro-biocides, this will shock the pan, and drain lines. After the first month the strip will release a metered amount of chemicals, safe but effective for the next 5 months to prevent microbial growths that cause odors and cause the drain line and pan to "stop-up" and cause water overflows. After six months the amount of chemical is depleted although the product is the same size. What is left is the empty honeycomb polymer core which as we mentioned above is wrapped in newspaper and thrown out with the trash. Wash your hands immediately after handling T.R. Bio Klean and do not rub eyes or nose.

