

Valve Core Replacing Tools



Valve Core Tools

1/4" and 5/16" SAE



32525



32515



32520



A-32000



32525-5/16"SAE



A-31999-R/10



A-31999-G/10

- Used for faster vacuum, charging and recovery
- Designed to remove and replace Schrader valve cores without losing refrigerant charge
- Increases evacuation and charging speeds by creating unrestricted access to the system
- 32525 and 32525-5/16" have a blank off valve and a 360° movable vacuum gauge access port which allows for easy access in tight spaces
- 5/16" is similar to 1/4" valve core tool but for use with R410A systems and mini splits with larger service ports

Valve Core Tools for 1/4" SAE

Designation	Description	Part No.
32525	Vacuum/Charging Valve with adjustable vacuum port	4687701
32515	Vacuum/Charging Valve with vacuum port	9880894
32520	Valve Core replacing Tool	9880893
32520-555	Replacement O-ring set 32525/32515	9880892
A-32000	Valve core Tool Contains 6 extra cores and 1 extracore remover and tap	9880890

Valve Core Tools for 5/16" SAE

Designation	Description	Part No.
32525-5/16" SAE	Vacuum/Charging Valve with adjustable vacuum port	4687740
32515-1/2"-20 UNF (5/16" SAE)	Vacuum/Charging Valve with vacuum port	4660915
32520-1/2"-20 UNF (5/16" SAE)	Valve Core replacing Tool	4660923
32520-1/2"-20 UNF (5/16" SAE)-555	Replacement O-ring set 32525/32515	4661245
A-31999-R/10	Valve core red, packaged 10 per	9883488
A-31999-G/10	Valve core green, packaged 10 per	9880864